

NEBO®

OMNI FISH DOCK LIGHT


OPERATION

Press & release the power button to cycle through light modes:

Off > Memory > White > Green

Press & hold for **UV**.

Smart Power Control (SPC) seamlessly transitions through light modes.



POWER INDICATOR

This product uses 4 LED lights just above the USB Port.

100% battery: 4 lights

75% battery: 3 lights

50% battery: 2 lights

25% battery: 1 light

BATTERY

This unit is powered by an internal rechargeable lithium ion battery and can not be replaced.



For more information, detailed video instructions, and warranty registration, visit **NEBOLIGHTS.com**.

PRODUCT GUARANTEE

If you experience a problem, please do not return to your local store. Please contact our Customer Service team at **800-255-6061** or **www.nebotools.com/contact**.

MODES	LUMENS	RUN TIME	METERS
WHITE HIGH	450	2.5h	33
WHITE LOW	45	10h	13
GREEN	100	7h	16
UV (395nm)	4	3h	7

MODE RECALL

Once the light has been ON for 8 seconds, the next Power Button push will turn the light OFF. After the unit has been turned OFF, the next button push will activate the **Last Used Mode**.

ADJUSTABLE BRIGHTNESS

Press & Hold the **Plus(+)** and **Minus(-)** buttons to adjust the brightness. The light will flash briefly once the maximum or minimum brightness level has been reached.

CHARGING

Use the included USB-C charging cable to recharge the Omni Fish Dock Light.

The last indicator light will flash while the unit is charging.

POWER BANK

To charge your phone or other USB device, simply plug the device into the USB-A Port.

This product is guaranteed against all defects in workmanship and materials for the original owner for one year from the date of purchase.

Alliance Consumer Group
700 Henrietta Creek Road
Roanoke, Texas 76262
800.255.6061

Made in China.